

## How to change the Channel and/or Address of the RF Gen2 Clicker:

1. Turn the response pad off.
2. Press and hold for two seconds the left and right arrow buttons at the top of the remote. (If you push the buttons and the pad turns on, you need to start over at step 1.)
3. Press and release the +/- button.
4. Input the two-digit channel # and press send.
5. Input the pad ID you want and press send twice.
6. The pad will power down and the channel and pad ID will be changed on the pad.

