

The Interwrite Mobi

Getting Connected

Complete the following steps to connect the Mobi to the computer.

1. Insert the RF Workspace Hub into the USB port on your computer. Your computer will automatically detect the USB devices. The blue LED on the Workspace RF Hub will light up when it is plugged in.
 2. Press the lighted Activation button on the RF Hub. The blue light will start blinking.
 3. Turn on the Mobi.
 4. Turn the Mobi over and press the **blue button** next to the battery opening to activate the Mobi's RF signal. You have two minutes to press the activation button on the Mobi.
- Note: When the two RF devices have successfully paired, the blue button on the RF Hub will stop blinking and remain a solid blue until either the computer or the Mobi is turned off. Pairing the RF devices is a one-time operation. They will recognize each other when the computer and the Mobi are turned on.

Viewing Device Manager

If changing the preferences are required for the Mobi, use the eInstruction Device Manager. Make sure the Interwrite Mobi is powered on. Complete the following steps to view the Device Manager.

1. Click the **eInstruction icon** in the System Tray on the Windows Task Bar to display the Device Manager menu.
2. Click **Device Manager**. The eInstruction Device Manager window opens.
3. Use the icons or Options menu to view or change the preferences on the Mobi.

